



# TUNER 1 – Pay to View/Freeview

## TO RECORD USING THE PVR (Personal Video Recorder) – 8 Gb Internal Storage

*When recording on TUNER 1 – Pay to View/Freeview, you can record and change input to view TUNER 2 – Freeview.*

### **For Instant Recording:**

Press the RECORD button (red circle/dot/HOLD) near the bottom. The current channel viewed will instant record. REC will appear on the screen. To stop recording, press the 'Stop' button.

**\*\*When recording on Tuner 1 & watching Tuner 2. Press the INPUT button to return to Tuner 1 before turning the TV off. This will ensure recording continues on Tuner 1.\*\***

**\*\*To playback recording, see paragraph at bottom of the page.**

### **For Timed Recording:**

1. Select the channel you would like to set a Timed Recording on and press the DISPLAY button twice.
2. Select the date and day, then select the right arrow on keypad and select the programme you wish to record.
3. Once selected, press OK on the remote. A recording menu will popup.
4. Select "Save" at the bottom of the screen and press OK to save settings.
5. Your programme is now set up to record, please ensure there is power going to the set (standby is fine) and the dish is locked on to the satellite to record successfully.

**\*\*To access your Timed Recordings, press the menu button, scroll down to 'Timer Setting' and press OK. To delete Timed Recordings, select recording, press OK. Scroll across to select OFF and press Save.**

## **TO SET THE CORRECT TIME**

1. Press Menu – right arrow to "System Setup" and press OK.
2. Scroll down to EPG and Time Setting – press OK.
3. Under EPG Default Settings it should be set at: Satellite | GMT offset UTC +12:00 | Summer time (select ON/OFF dependant on daylight savings)
4. Press EXIT to return to TV, the settings are automatically saved.

## **TO PLAYBACK RECORDED PROGRAMME**

1. Press the Menu button – and navigate to 'Multimedia'
2. Scroll down and select 'Media Player'
3. Scroll down and select 'Record'. Your recording should appear on the right hand side of the screen.
4. Press the Right arrow and select the recording. To play the recording, press ok.
5. To pause your recording, press the SW button.
6. When you have finished viewing the recording, press the STOP button. Press exit until you return to the TV screen.
7. To delete a file - Press the Yellow button to select the recorded file and press EXIT to confirm deletion.

**\*\*Please be aware of the times when recording as you cannot overlap timed recordings\*\***

**\*\*For standby recording on two tuners simultaneously you must set up your timed recording on Tuner 1, then move to Tuner 2 and set up your timed recording. You can only turn on standby mode from Tuner 2.\*\***



# TUNER 2 - Freeview

## TO RECORD USING THE PVR (Personal Video Recorder) – 8Gb Internal Storage

*When recording on TUNER 2 –Freeview, you cannot change input and watch TUNER 1; therefore you must record your programme on TUNER 1 and watch TUNER 2.*

### **For Instant Recording:**

Press the RECORD button (red circle/dot/HOLD near the bottom) ONCE on the remote and the current channel viewed will instant record. Once recording has started, press the record button a second time to clear the screen. To stop recording, press the STOP button.

**\*\*When recording on Tuner 1 & watching Tuner 2. Press the INPUT button to return to Tuner 1 before turning the TV off. This will ensure recording continues on Tuner 1.\*\***

**\*\*To playback recording, see below.**

### **For Timed Recording:**

1. Press the DISPLAY button on the remote to ensure the time is correct. If the time is not correct press MENU, scroll across to TIME and scroll down to TIME ZONE and ensure you are on New Zealand GMT+12.
2. Press 'Display' button and then 'EPG' button to open 'Programme Guide'
3. Use the up or down arrow keys to select the Freeview Channel you wish to record
4. Press the right arrow to scroll across and select the programme you wish to record. Once you have highlighted the programme press the RECORD button (red circle/dot/HOLD). Scroll down to the Mode AUTO and right arrow to change from AUTO to ONCE, check that your start and end time and date are correct and relate to the programme you wish to record press OK to accept and confirmation or alter as required. The programme will be added to your schedule list.
5. If you find that the EPG Programme Guide isn't displaying all channels to record, please follow process below:
  - a. Press 'Display' button and then 'EPG' button to open Programme Guide
  - b. Press the RECORD button (red circle/dot)
  - c. Scroll down to 'Mode Auto' and press the right arrow to edit 'Start Time' and 'End Time'
6. You can now turn the TV off to standby mode and the Timed Recording can record in standby mode without needing the TV on. During recording the LED standby light will remain blue.

## **TO PLAYBACK RECORDED PROGRAMME**

1. Press the INPUT button on the remote.
2. Scroll down to 'USB' & press the OK button.
3. Right arrow to 'MOVIE' & press the OK button.
4. Press the OK button on 'C'
5. Select 'MSTPVR' & press the OK button.
6. Select the recording you wish to play back & press the PLAY/PAUSE button.
7. To return to satellite TV. Press the INPUT button, highlight 'Tuner 1' or 'Tuner 2' & press the OK button.

## **TO VIEW SCHEDULED RECORDINGS AND DELETING RECORDINGS:**

1. Press 'Display' button and then 'EPG' button to open 'Programme Guide'
2. Press the Yellow button to view Scheduled List. Here is where you can view your scheduled recordings.
3. If you wish to delete your scheduled recordings, press the Red button to delete
4. Press Exit and to go back to TV viewing

**\*\*Please be aware of the times when recording as you cannot overlap timed recordings\*\***

**\*\*For standby recording on two tuners simultaneously you must set up your timed recording on Tuner 1, then move to Tuner 2 and set up your timed recording. You can only turn on standby mode from Tuner 2.\*\***