


How to Update Tuner 1 – WHDTV-T


1. Supply power then turn the TV on and wait until you have an operating channel
2. Press INPUT on the remote to ensure you are on TUNER 1 – Pay-To-View/Freeview
3. Press MENU on the remote
4. Right arrow across to TOOLS in red, press OK
5. Scroll down to Remove USB device safely and press OK
6. Ensure USB-A is the option to remove, then scroll down and press OK
7. Insert your USB stick into the SIDE port of the TV
8. Your grey options will change to white as it registers the USB, now scroll to Upgrade by USB and press OK



9. Scroll down to 'Keeping DBS and setting' please highlight this and RIGHT ARROW across to select NO
10. Scroll down to START, press OK



11. Press ok for YES at the question in the box - "burnflash" will run 100%



12. Once the TV has reloaded, all the new channels will be loaded

13. Unplug the Power first and then remove the USB Stick.